


Negative Space
Stage right interior




Negative Space black wooden dimensions
Red plasterboard for 120 x 250 sheets

2 lengths at 361 (small gap so to easily fit board)
6 lengths at 352 (minus width of timber 4cm)
9 lengths at 120 +/- Pros top & bottom and inserts

Drawings made with dimensions of timber at 4 x 6 x 400 cm


Negative Space
Back wall interior



2 lengths at 4m
6 lengths at 352
6 lengths at 112



Drawings made with dimensions of timber at 4 x 6 x 400 cm
If lengths of timber are 410 then top an bottom length can be cut so
that the offcuts are internal alternative drawings can be provided.

Negative Space
Stage left interior





Negative Space
Exterior support frames

Exterior support frames SR Middle





Braces 2cm thick
to attach frames
to interior walls





Exterior support frames SL Middle





Exterior support frames SL & SR Back




Exterior support frames Back




Frames for platform exterior SR addition support using offcuts



Negative Space
Floor interior ply positions and trap doors




Negative Space
Floor frame




Negative Space
Position of support frames

400 lengths used to tie in support structures at base & top at 200

400 lengths used to tie in support structures at base & top at 200



Negative Space
Floor OSB dimensions



15mm OSB 2500 x 1200 6 sheets in total
3 @ 2500 x 1200
2 @ 750 x 1200
2 @ 1500 x 1200
1 @ 1200 x 1200

Negative Space

Plasterboard drawing based on 250 x 120 x 9.5

Replacement board for extra performances 

16 Boards required for 1 performance
11 Full sheets are destroyed - drawings can be provided for requirements for additional performances

